GGM NVR0216P

How to restore default system Settings

Valid for those references :

- GGM KITIP24C5MP
- GGM KITIP48C5MP
- GGM NVRL0104
- GGM NVRL0104P
- GGM NVRL0108P
- GGM NVR0208P
- GGM NVR0216P
- GGM NVR02168P
- GGM NVR8
- GGM NVR16
- GGM NVR32
- GGM NVRE0104P
- GGM NVRE0108P

Caution : For any configuration, you need to connect an HDMI display device directly to the back of the recorder (Monitor or TV)

Load Default

Note: Restoring the default settings will not delete the recordings and images saved on the hard drive.

Go to **SETUP,** then **SYSTEM** and **MAINTENANCE** and choose **LOAD DEFAULT** Menu.

You can choose to reset all settings at once, or just settings on specific menus. Check the items you want restore, or check **Select All** to choose all items. Click **Apply** to load default settings of your chosen items.

Apply. System will restart.