

GGM CCKITAHD

Export a recording (to a USB Stick)




Valid for those references :

- GGM CCKITAHD
- GGM CCKITAHD4
- GGM CCKITAHD8
- GGM CCEL2KITAHD4
- GGM CCKITAHD 1080P
- GGM CCAHDXX
- GGM CCELXX

Where ?

Go to the Main Menu and then Record Search.



Here, you can select camera and date you want to see. Then Go to READ

Next, put a USB stick into your recorder. (3 USB Ports)



Bar graph appears on the bottom, with RED or green color according the type of recording (Normal or alarm).

Choose the time you want to Export by positioning the cursor on the start range and click on this button:



First Red Line should appear (Start Range)




Then, click on the End Range – A Second Red Line Should appear.



Last, click on **SAVE** Button :



Select the type of Backup File (H264 and AVI) and **SAVE**



Choose the path you want to **SAVE** your recording file. Then **GO**

