



### **GGM KITIP24xx-48xx**

# **How to configure SMTP Server**



### Valid for those references:

- GGM NVRL0104
- GGM NVRL0104P
- GGM NVRL0108P
- GGM NVRE0104P
- GGM NVRE0108P
- GGM KITIP24C5MP
- GGM KITIP48C5MP

You can receive an email as soon as an alarm is activated in your recorder.

Example: You want to receive an email as soon as motion detection is triggered.




Le <u>SMTP</u> (Simple Mail Transfer Protocol) is the standard protocol for email services on a TCP/IP network. SMTP provides the ability to send and receive email messages.





#### Go to Main Menu then SETUP and SETUP and Choose Email



Fill in your information of your SMTP server or according your provider

<u>Caution</u>: Ask those informations from your IT administrator or from your provider.

**Example**: Orange - SMTP Server: **smtp.orange.fr** and specific Port...

#### Other Example with Gmail:

<u>Server (smtp)</u>: smtp.gmail.com

Port: 465

Encryption: SSL / TLS
User Name: Gmail address
Password: Gmail Password
Sender: email header

Receiver1: Destination email 1 Receiver2: Destination email 2

...

SAVE and use Test Email button for Test.





## **Email Schedule**

You need to configure the schedule to fully implement the Email notification

